

DMX Values

15Ch	Channel	Function	Value	Percent/Setting
	1	Dimmer	000ó 255	0-100%
	2	Dimmer Fine	000ó 255	0-100%
	3	Red	000ó 255	0-100%
	4	Red Fine	000ó 255	0-100%
	5	Green	000ó 255	0-100%
	6	Green Fine	000ó 255	0-100%
	7	Blue	000ó 255	0-100%
	8	Blue Fine	000ó 255	0-100%
	9	Amber	000ó 255	0-100%
	10	Amber Fine	000ó 255	0-100%
	11	Lime	000ó 255	0-100%
	12	Lime Fine	000ó 255	0-100%
	13	Strobe	000ó 010 011ó 255	No function Strobe, slow to fast
	14	Virtual Color Wheel	000ó 005 006ó 013 014ó 021 022ó 028 029ó 035 036ó 043 044ó 051 052ó 059 060ó 067 068ó 075 076ó 083 084ó 091 092ó 099 100ó 107 108ó 115 116ó 121 122ó 130 131ó 138 139ó 146 147ó 154 155ó 162 163ó 170 171ó 178 179ó 186 187ó 194 195ó 202 203ó 210 211ó 218 219ó 226 227ó 234 235ó 242 243ó 250 251ó 255	No function R4590 - CalColor 90 Yellow R11 - Light Straw R312 - Canary R03 - Dark Bastard Amber R18 - Flame R20 - Medium Amber R21 - Golden Amber R26 - Light Red R27 - Medium Red R33 - No Color Pink R337 - True Pink R38 - Light Rose R41 - Salmon R42 - Deep Salmon R44 - Middle Rose R349 - Fisher Fuchsia R54 - Special Lavender R64 - Light Steel Blue R364 - Blue Bell R65 - Daylight Blue R80 - Primary Blue R81 - Urban Blue R82 - Surprise Blue R382 - Congo Blue R83 - Medium Blue R383 - Sapphire Blue R90 - Dark Yellow Green R91 - Primary Green R92 - Turquoise R93 - Blue Green R393 - Emerald Green No function

DMX Values (Cont.)

15Ch (Cont.)	Channel	Function	Value	Percent/Setting
	15	Color Temperature	000 ∘ 005	No function
			006 ∘ 025	2800K
			026 ∘ 050	3200K
			051 ∘ 075	3500K
			076 ∘ 100	4000K
			101 ∘ 125	4500K
			126 ∘ 150	5000K
			151 ∘ 175	5600K
			176 ∘ 200	6000K
			201 ∘ 225	6500K
			226 ∘ 255	No function

13Ch	Channel	Function	Value	Percent/Setting
	1	Dimmer	000 ∘ 255	0–100%
	2	Dimmer Fine	000 ∘ 255	0–100%
	3	Red	000 ∘ 255	0–100%
	4	Red Fine	000 ∘ 255	0–100%
	5	Green	000 ∘ 255	0–100%
	6	Green Fine	000 ∘ 255	0–100%
	7	Blue	000 ∘ 255	0–100%
	8	Blue Fine	000 ∘ 255	0–100%
	9	Amber	000 ∘ 255	0–100%
	10	Amber Fine	000 ∘ 255	0–100%
	11	Lime	000 ∘ 255	0–100%
	12	Lime Fine	000 ∘ 255	0–100%
	13	Strobe	000 ∘ 010	No function
			011 ∘ 255	Strobe, slow to fast

12Ch	Channel	Function	Value	Percent/Setting
	1	Dimmer	000 ∘ 255	0–100%
	2	Red	000 ∘ 255	0–100%
	3	Green	000 ∘ 255	0–100%
	4	Blue	000 ∘ 255	0–100%
	5	Amber	000 ∘ 255	0–100%
	6	Lime	000 ∘ 255	0–100%
	7	Strobe	000 ∘ 010	No function
			011 ∘ 255	Strobe, slow to fast

DMX Values (Cont.)

12Ch (Cont.)	Channel	Function	Value	Percent/Setting
8	Virtual Color Wheel	000	005	No function
		006	013	R4590 - CalColor 90 Yellow
		014	021	R11 - Light Straw
		022	028	R312 - Canary
		029	035	R03 - Dark Bastard Amber
		036	043	R18 - Flame
		044	051	R20 - Medium Amber
		052	059	R21 - Golden Amber
		060	067	R26 - Light Red
		068	075	R27 - Medium Red
		076	083	R33 - No Color Pink
		084	091	R337 - True Pink
		092	099	R38 - Light Rose
		100	107	R41 - Salmon
		108	115	R42 - Deep Salmon
		116	121	R44 - Middle Rose
		122	130	R349 - Fisher Fuchsia
		131	138	R54 - Special Lavender
		139	146	R64 - Light Steel Blue
		147	154	R364 - Blue Bell
		155	162	R65 - Daylight Blue
		163	170	R80 - Primary Blue
		171	178	R81 - Urban Blue
		179	186	R82 - Surprise Blue
		187	194	R382 - Congo Blue
195	202	R83 - Medium Blue		
203	210	R383 - Sapphire Blue		
211	218	R90 - Dark Yellow Green		
219	226	R91 - Primary Green		
227	234	R92 - Turquoise		
235	242	R93 - Blue Green		
243	250	R393 - Emerald Green		
251	255	No function		
9	Color Temperature	000	005	No function
		006	025	2800K
		026	050	3200K
		051	075	3500K
		076	100	4000K
		101	125	4500K
		126	150	5000K
		151	175	5600K
		176	200	6000K
		201	225	6500K
		226	255	No function

DMX Values (Cont.)

12Ch (Cont.)	Channel	Function	Value	Percent/Setting
	10	Auto Programs	000 ó 010	No function
			011 ó 060	Auto 1
			061 ó 110	Auto 2
			111 ó 160	Auto 3
			161 ó 210	Auto 4
			211 ó 255	Auto 5
	11	Auto Speed	000 ó 255	Slow to fast
	12	Dimmer Speed	000 ó 051	Preset dimmer speed from display menu
			052 ó 101	Dimmer speed mode off
			102 ó 152	Dimmer speed mode 1 (fastest)
			153 ó 203	Dimmer speed mode 2
			204 ó 255	Dimmer speed mode 3 (slowest)

10Ch	Channel	Function	Value	Percent/Setting
	1	Dimmer	000 ó 255	0-100%
	2	Dimmer Fine	000 ó 255	0-100%
	3	Red	000 ó 255	0-100%
	4	Green	000 ó 255	0-100%
	5	Blue	000 ó 255	0-100%
	6	Amber	000 ó 255	0-100%
	7	Lime	000 ó 255	0-100%
	8	Strobe	000 ó 010	No function
			011 ó 255	Strobe, slow to fast

DMX Values (Cont.)

10Ch (Cont.)	Channel	Function	Value	Percent/Setting
9	9	Virtual Color Wheel	000 ∘ 005	No function
			006 ∘ 013	R4590 - CalColor 90 Yellow
			014 ∘ 021	R11 - Light Straw
			022 ∘ 028	R312 - Canary
			029 ∘ 035	R03 - Dark Bastard Amber
			036 ∘ 043	R18 - Flame
			044 ∘ 051	R20 - Medium Amber
			052 ∘ 059	R21 - Golden Amber
			060 ∘ 067	R26 - Light Red
			068 ∘ 075	R27 - Medium Red
			076 ∘ 083	R33 - No Color Pink
			084 ∘ 091	R337 - True Pink
			092 ∘ 099	R38 - Light Rose
			100 ∘ 107	R41 - Salmon
			108 ∘ 115	R42 - Deep Salmon
			116 ∘ 121	R44 - Middle Rose
			122 ∘ 130	R349 - Fisher Fuchsia
			131 ∘ 138	R54 - Special Lavender
			139 ∘ 146	R64 - Light Steel Blue
			147 ∘ 154	R364 - Blue Bell
			155 ∘ 162	R65 - Daylight Blue
			163 ∘ 170	R80 - Primary Blue
			171 ∘ 178	R81 - Urban Blue
			179 ∘ 186	R82 - Surprise Blue
			187 ∘ 194	R382 - Congo Blue
195 ∘ 202	R83 - Medium Blue			
203 ∘ 210	R383 - Sapphire Blue			
211 ∘ 218	R90 - Dark Yellow Green			
219 ∘ 226	R91 - Primary Green			
227 ∘ 234	R92 - Turquoise			
235 ∘ 242	R93 - Blue Green			
243 ∘ 250	R393 - Emerald Green			
251 ∘ 255	No function			
10	10	Color Temperature	000 ∘ 005	No function
			006 ∘ 025	2800K
			026 ∘ 050	3200K
			051 ∘ 075	3500K
			076 ∘ 100	4000K
			101 ∘ 125	4500K
			126 ∘ 150	5000K
			151 ∘ 175	5600K
			176 ∘ 200	6000K
			201 ∘ 225	6500K
226 ∘ 255	No function			

DMX Values (Cont.)

7Ch	Channel	Function	Value	Percent/Setting
	1	Dimmer	000↻ 255	0–100%
	2	Red	000↻ 255	0–100%
	3	Green	000↻ 255	0–100%
	4	Blue	000↻ 255	0–100%
	5	Amber	000↻ 255	0–100%
	6	Lime	000↻ 255	0–100%
	7	Strobe	000↻ 010 011↻ 255	No function Strobe, slow to fast

5Ch	Channel	Function	Value	Percent/Setting
	1	Red	000↻ 255	0–100%
	2	Green	000↻ 255	0–100%
	3	Blue	000↻ 255	0–100%
	4	Amber	000↻ 255	0–100%
	5	Lime	000↻ 255	0–100%

3Ch	Channel	Function	Value	Percent/Setting
	1	Dimmer	000 ∘ 255	0–100%
	2	Virtual Color Wheel	000 ∘ 005	No function
			006 ∘ 013	R4590 - CalColor 90 Yellow
			014 ∘ 021	R11 - Light Straw
			022 ∘ 028	R312 - Canary
			029 ∘ 035	R03 - Dark Bastard Amber
			036 ∘ 043	R18 - Flame
			044 ∘ 051	R20 - Medium Amber
			052 ∘ 059	R21 - Golden Amber
			060 ∘ 067	R26 - Light Red
			068 ∘ 075	R27 - Medium Red
			076 ∘ 083	R33 - No Color Pink
			084 ∘ 091	R337 - True Pink
			092 ∘ 099	R38 - Light Rose
			100 ∘ 107	R41 - Salmon
			108 ∘ 115	R42 - Deep Salmon
			116 ∘ 121	R44 - Middle Rose
			122 ∘ 130	R349 - Fisher Fuchsia
			131 ∘ 138	R54 - Special Lavender
			139 ∘ 146	R64 - Light Steel Blue
			147 ∘ 154	R364 - Blue Bell
			155 ∘ 162	R65 - Daylight Blue
			163 ∘ 170	R80 - Primary Blue
			171 ∘ 178	R81 - Urban Blue
			179 ∘ 186	R82 - Surprise Blue
			187 ∘ 194	R382 - Congo Blue
			195 ∘ 202	R83 - Medium Blue
			203 ∘ 210	R383 - Sapphire Blue
			211 ∘ 218	R90 - Dark Yellow Green
			219 ∘ 226	R91 - Primary Green
			227 ∘ 234	R92 - Turquoise
			235 ∘ 242	R93 - Blue Green
			243 ∘ 250	R393 - Emerald Green
			251 ∘ 255	No function
	3	Color Temperature	000 ∘ 005	No function
			006 ∘ 025	2800K
			026 ∘ 050	3200K
			051 ∘ 075	3500K
			076 ∘ 100	4000K
			101 ∘ 125	4500K
			126 ∘ 150	5000K
			151 ∘ 175	5600K
			176 ∘ 200	6000K
			201 ∘ 225	6500K
			226 ∘ 255	No function