

DMX Values

9CH	Channel	Function	Value	Percent/Setting
	1	Fog	000 ó 010 011 ó 255	No function Fog on
	2	Dimmer	000 ó 255	0–100%
	3	Red	000 ó 255	0–100%
	4	Green	000 ó 255	0–100%
	5	Blue	000 ó 255	0–100%
	6	Amber	000 ó 255	0–100%
	7	Strobe	000 ó 255	0–100%
	8	Auto Color	000 ó 010 011 ó 255	No function Color mixing (See the User Manual for more detailed DMX values.)
	9	Auto Speed	000 ó 255	0–100%