

QUICK REFERENCE GUIDE



Strike 1- V1.230817

DMX Values

7CH

Channel	Function	Value	Percent/Setting
1	White	000 ⇄ 255	0–100%
2	White fine	000 ⇄ 255	0–100%
3	Amber	001 ⇄ 255	Off
4	Amber fine	000 ⇄ 255	0–100%
5	Strobe	000 ⇄ 010	No function
		011 ⇄ 255	Strobe, slow to fast
6	Auto Program	000 ⇄ 010	No function
		011 ⇄ 080	Auto 1, slow to fast
		081 ⇄ 160	Auto 2, slow to fast
		161 ⇄ 240	Auto 3, slow to fast
		241 ⇄ 255	No function
7	Dimmer Speed*	000 ⇄ 051	Current dimmer speed mode
		052 ⇄ 101	Dimmer speed mode off (linear dimmer)
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)



*Hold the desired Dimmer Speed value for 3 seconds, then release. This changes the Dimmer Mode setting in the menu.

6CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Fine dimmer	000 ⇄ 255	0–100%
3	Red shift	000	On
		001 ⇄ 255	Off
4	Strobe	000 ⇄ 010	No function
		011 ⇄ 255	Strobe, slow to fast
5	Auto program	000 ⇄ 010	No function
		011 ⇄ 080	Auto 1, slow to fast
		081 ⇄ 160	Auto 2, slow to fast
		161 ⇄ 240	Auto 3, slow to fast
		241 ⇄ 255	No function
6	Dimmer speed*	000 ⇄ 051	Current dimmer speed mode
		052 ⇄ 101	Dimmer speed mode off (linear dimmer)
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

5CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Red shift	000	On
		001 ⇄ 255	Off
3	Strobe	000 ⇄ 010	No function
		011 ⇄ 255	Strobe, slow to fast
4	Auto program	000 ⇄ 010	No function
		011 ⇄ 080	Auto 1, slow to fast
		081 ⇄ 160	Auto 2, slow to fast
		161 ⇄ 240	Auto 3, slow to fast
		241 ⇄ 255	No function
5	Dimmer speed*	000 ⇄ 051	Current dimmer speed mode
		052 ⇄ 101	Dimmer speed mode off (linear dimmer)
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

4CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Fine dimmer	000 ⇄ 255	0–100%
3	Red shift	000	On
		001 ⇄ 255	Off
4	Dimmer speed*	000 ⇄ 051	Current dimmer speed mode
		052 ⇄ 101	Dimmer speed mode off (linear dimmer)
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

3Ch

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%
2	Red shift	000	On
		001 ⇄ 255	Off
3	Dimmer speed*	000 ⇄ 051	Current dimmer speed mode
		052 ⇄ 101	Dimmer speed mode off (linear dimmer)
		102 ⇄ 152	Dimmer speed mode 1 (fastest)
		153 ⇄ 203	Dimmer speed mode 2
		204 ⇄ 255	Dimmer speed mode 3 (slowest)

1CH

Channel	Function	Value	Percent/Setting
1	Dimmer	000 ⇄ 255	0–100%